

1. Thread tube A into the base.
2. Thread tube B onto tube A.
3. Place socket assembly onto tube B.
4. Place hand knob assembly onto socket assembly.
5. Place shade onto socket and tighten socket ring.

