s e a s c a p e

Seascape Lamps PO Box 810 Freedom, CA 95019

> Tel: 800 444 0233 Fax: 831 728 0658

Semi-Flush

Turn off power at the circuit panel box. Make sure junc-

CAUTION:

tion box is firmly installed to support the lighting fixture. Check your j-box manufacturer's listing for the box. For instance, a Raco brand 146 actagon box is listed for 50 lbs. static (fixture) while a Raco 296 is listed for 75 lbs. static. WARNING: This equipment must be installed by a licensed electrician or other qualified person. Support Cable J-Box J-Box Canopy Canopy Mounting Plate

NEC: 314.27 Outlet Boxes.

(A) Boxes at Luminaire (Lighting Fixture) Outlets. Boxes used at luminaire (lighting fixture) or lampholder outlets shall be designed for the purpose. At every outlet used exclusively for lighting, the box shall be designed or installed so that a luminaire (lighting fixture) may be attached.

(B) Maximum Luminaire (Fixture) Weight. Outlet boxes or fittings installed as required by 314.23 shall be permitted to support luminaires (lighting fixtures) weighing 23 kg (50 lb) or less. A luminaire (lighting fixture) that weighs more than 23 kg (50 lb) shall be supported independently of the outlet box unless the outlet box is listed for the weight to be supported.

Tip: Fasten Mounting Plate to fixture **after** all connections are complete

Use included ROPE GRIP to secure fixture to a support independent of the J-Box.

